

TABELA PARA CONVERSÃO D PRESSÕES

	Torr	mbar	Pa	Bar	Atm
Torr	1	1.33	133.3	1.33×10^{-3}	1.31×10^{-3}
mbar	7.5×10^{-1}	1	100	1×10^{-3}	9.8×10^{-4}
Pa	7.5×10^{-3}	1×10^{-2}	1	1×10^{-5}	9.8×10^{-6}
Bar	750	1×10^3	1×10^5	1	9.8×10^{-1}
Atm	760	1.04×10^3	1.01×10^5	1.01	1